



USER MANUAL PENTA CITY 300



Content

1. Opening the Quick Lock door of the Penta City 300 system p. 1
2. Closing the Quick Lock door of the Penta City 300 system p. 3





1. Opening the Quick Lock door of the Penta City 300 system

1. Unlock the door lock by pressing the safety cover.
2. Pull the locking handle to the front of the vehicle to open the door. The hook profile can now be unlatched.
3. Pull or push the system open.





Opening the Quick Lock door of the Penta City 300 system

4. Pull the door stopper out, as demonstrated, to keep the system open.





2. Closing the Quick Lock door of the Penta City 300 system

1. Open the system a bit further and push the door stopper inside, as demonstrated.
2. Close up the system by pulling.





Closing the Quick Lock door of the Penta City 300 system

3. Hook up the hook profile of the Quick Lock door behind the front corner pillar.
4. Close the door lock by pushing the handle.



Penta City goes the last mile

